


# AstroCore Wiring Diagram



Visit <https://astrocoredepot.com> for detailed installation instructions.

Receiver must have 5v power through CH1 or CH2 pins to power on.