


# AstroCore Pro Wiring Diagram For Motion Sensing & RC



Use the QR Code to view the  
AstroCore Installation Instructions

Receiver must have 5v power through  
CH1 or CH2 pins to power on.